Determining the Relative Reductions of BMPs in the Phase II WIPs

Matt Johnston, University of MD College Park, mjohnston@chesapeakebay.net, 410-267-5707

Analysis conducted by the Chesapeake Bay Program's Scenario Builder and Modeling Teams

April 11, 2013

Special thanks to: Sucharith Ravi, Amanda Pruzinsky, Jessica Rigelman and Jeremy Hanson

Objectives

- Identify the most common BMPs described in the Phase II Watershed Implementation Plans (WIPs).
- Identify the BMPs that contribute to the greatest reductions in nitrogen, phosphorus and sediment described in the Phase II WIPs.

Method

- Create a NO ACTION Scenario.
- Determine load reductions between Phase II WIP Scenario and NO ACTION.
- Isolate each BMP in a separate scenario using Scenario Builder processing rules.
- Determine load reductions from the isolated BMP scenario to the NO ACTION.
- Compare the load reductions from the isolated scenarios to those from the Phase II WIP to determine a percent share of the reductions attributable to each BMP.

Most Common Agricultural BMP Phase II WIP Acres Watershed-Wide

ВМР	Acres
Conservation Plans	6,811,304
Enhanced Nutrient Application Management	2,082,419
Other Conservation-Till	2,002,283
Decision Agriculture	1,143,587
Cover Crop	1,136,034
Nutrient Application Management on Pasture	1,033,992
Nutrient Application Management on Crop	995,989
Prescribed Grazing	948,389
Land Retirement	609,407
Liquid & Poultry Injection	371,823
Continuous NoTill	321,901
Commodity Cover Crop	307,143
Precision Intensive Rotational Grazing	286,210
Forest Buffers	277,913
Crop Irrigation Management	251,767

Most Common Urban BMP Phase II WIP Acres Watershed-Wide

ВМР	Acres
Filtering Practices	848,488
Infiltration Practices	655,730
Wet Ponds & Wetlands	411,753
Extended Dry Ponds	225,756
Dry Ponds	174,664
Forest Harvesting BMPs	164,821
Extractive Erosion and Sediment Control	149,635
Forest Conservation	113,977
SWM by Era (1985-2002)	98,803
Street Sweeping	89,474
Erosion and Sediment Control	83,551
Retrofit Stormwater Management	69,208
SWM by Era (2002-2010)	65,668
Impervious Surface & Urban Growth	
Reduction	61,956
Abandoned Mine Reclamation	61,285

BMP Units in Phase II WIPs Watershed-wide

ВМР	Measurement	Units
Dirt&Gravel Road E&S	feet	28,929,712
Urban Stream Restoration	feet	2,332,664
NonUrban Stream Restoration	feet	1,128,757
Manure Transport Outside CBWS	tons	572,999
Street Sweeping	lbs	9,628,448
Livestock+Poultry Waste Management Systems	AU	2,772,306
Livestock+Poultry Mortality Composting	AU	71,664
Septic Denitrification	systems	266,978
Septic Connections	systems	232,085
Septic Pumping	systems	141,963





WIP Relative Load Reductions Source Sectors BMPs

Jeff Sweeney
Environmental Protection Agency
Chesapeake Bay Program Office
jsweeney@chesapeakebay.net
410-267-9844

Agriculture Workgroup Meeting
U.S. Fish and Wildlife Chesapeake Bay Field Office
Annapolis, MD
April 11, 2013



Agriculture Practices

LandDatira	Land Datirament	Droo Dot Crozing	Dropprihad Crazing	
LandRetire	Land Retirement	PrecRotGrazing	Prescribed Grazing	
ForestBuffers	Forest Buffers	UpPrecIntRotGraze	Precision Intensive Rotational Grazing	
ConserveTill	Conservation Tillage	MortalityComp	Mortality Composting	
CoverCrop	Cover Crop	EffNutManDecAgVA	Decision Agriculture	
AWMS	Animal Waste Management Systems	ForestBuffersTrp	Forest Buffers on Fenced Pasture Corridor	
GrassBuffers	Grass Buffers	NoTill	Continuous NoTill	
EnhancedNM	Enhanced Nutrient Application Management	WaterContStruc	Water Control Structures	
CarSeqAltCrop	Carbon Sequestration	Cropirrmgmt	Crop Irrigation Management	
ConPlan	Conservation Plans	EffNutManEnhanceVA	Enhanced Nutrient Application Management	
ComCovCrop	Commodity Cover Crop	NonUrbStrmRest	NonUrban Stream Restoration	
WetlandRestore	Wetland Restoration	LoafLot	Loafing Lot Management	
DecisionAg	Decision Agriculture	OSWnoFence	Pasture Alternative Watering	
PastFence	Stream Access Control with Fencing	ConserveTillom	Conservation-Till Specialty Crops	
GrassBuffersTrp	Grass Buffers on Fenced Pasture Corridor	TreePlantTrp	Tree Planting on Fenced Pasture Corridor	
DairyPrecFeed	Dairy Precision Feeding	PoultryPhytase	Poultry Phytase	
Poultrylnjection	Poultry Injection	SwinePhytase	Swine Phytase	
TreePlant	Tree Planting	BioFilters	BioFilters	
CaptureReuse	Capture & Reuse	HorsePasMan	Horse Pasture Management	
ManureTransport	Manure Transport	LagoonCovers	Lagoon Covers	
ContinuousNT	Continuous NoTill	NutMan	Nutrient Application Management on Crop	
BarnRunoffCont	Barnyard Runoff Control	Alum	Ammonia Emission Reductions (Alum)	
LiquidInjection	Liquid Injection			



Urban/Suburban Practices

Infiltration Infiltration Practices
Filter Filtering Practices

Urban Nutrient Management

BioRet BioRetention

WetPondWetland Wet Ponds & Wetlands
SWMEra0210 SWM by Era (2002-2010)
ForestCon Forest Conservation Act

ForestBufUrban Forest Buffers

ExtDryPonds Extended Dry Ponds

AbanMineRec Abandoned Mine Reclamation
EandS Erosion and Sediment Control
RetroSWM Retrofit Stormwater Management

SWMEra8502 SWM by Era (1985-2002)

EandSext Extractive Erosion and Sediment Control

UrbStrmRest Urban Stream Restoration

barTOpul Enhanced Construction EandS

VegOpChan Vegetated Open Channel

ImpSurRed Impervious Surface Reduction

UrbanTreePlant Tree Planting
DryPonds Dry Ponds

StreetSweep Street Sweeping

PermPav Permeable Pavement
UrbGrowRed Urban Growth Reduction



Resource Practices – Septic – Wastewater+CSO

Resource Practice	S	Septic	Wastewater+CSO
ForHarvestBMP	Forest Harvesting BMPs	[Septic Connections]	
DirtGravel	Dirt&Gravel Road E&S	[Septic Denitrification]	
		[Septic Pumping]	

Method

- Create a NO ACTION Scenario.
- Determine load reductions between Phase II WIP Scenario and NO ACTION.
- Isolate each BMP in a separate scenario using Scenario Builder processing rules.
- Determine load reductions from the isolated BMP scenario to the NO ACTION.
- Compare the load reductions from the isolated scenarios to those from the Phase II WIP to determine a percent share of the reductions attributable to each BMP.
- For wastewater, the contribution to the total load reduction compares current discharges (2011) to WIP discharges while BMPs outside wastewater compare NO ACTION to WIPs.






Nitrogen Reductions

Relative influence on load reductions to the WIPs




CB Watershed - absolute million lbs.






Nitrogen Relative Load Reductions CB Watershed – as percent






Pennsylvania






Nitrogen Relative Load Reductions Maryland






Nitrogen Relative Load Reductions Virginia







Nitrogen Relative Load Reductions West Virginia























Phosphorus Reductions

Relative influence on load reductions to the WIPs




Phosphorus Relative Load Reductions CB Watershed






Phosphorus Relative Load Reductions Pennsylvania






Phosphorus Relative Load Reductions






Phosphorus Relative Load Reductions








Phosphorus Relative Load Reductions West Virginia






Phosphorus Relative Load Reductions






Phosphorus Relative Load Reductions New York





Phosphorus Relative Load Reductions

District of Columbia








Sediment (Total Suspended Solids) Reductions


Relative influence on load reductions to the WIPs




Sediment Relative Load Reductions CB Watershed























Sediment Relative Load Reductions West Virginia






Delaware





Sediment Relative Load Reductions New York





District of Columbia

